



* M_2 used in lateral stability is the larger first order factored end moment