



\*  $M_2$  used in lateral stability is the larger first order factored end moment